



"Front - low view" of all connections on "control side" of solenoids. Dotted lines are heavy cables that the installer must connect



"Right - end view" of all connections on "power side" of solenoids. Dotted lines are heavy cables that the installer must connect



Fault search diagram for 12-24V serial parallel switch box for Sidepower 10 & 15HP '99 mod +
No. for 10Hp : 10112-A
No. for 15Hp : 15112-A


SIDEPOWER THRUSTERS
Sleipner Motor AS
N-1612 FREDRIKSTAD

Draw. no: S-2001/1
Date: 18.05.2001

Connections on the controller

Brown
Blue
Violet

White
Black
Red



Fault search diagram for 12-24V serial parallell switch
box for Sidepower 10 & 15HP '99 mod +
No. for 10Hp : 10112-A
No. for 15Hp : 15112-A

SIDEPOWER THRUSTERS
Sleipner Motor AS
N-1612 FREDRIKSTAD

Draw. no:S-2001/2
Date: 18.05.2001

Black
Grey
Direct to
thruster